

WASTE SYSTEM INSTALLATION GUIDE



INSTALLATION STEPS

- 1: **Place Waste System** in cabinet opening and determine location and screw through the floor mount brackets into the floor of the cabinet (screws not included).
- 2: **Place door onto front of Waste System** and fasten by screwing through door mounting brackets into door styles/uprights (screws not included).
- 3: For final placement **Waste System can be adjusted left/right or front/back** using the slotted holes in the floor mount brackets. Set screws in the door mounting brackets allow for tilt control if needed.
- 4: **Install screws** at anti-deflection screw location after completing the final placement of the waste system. Please see illustration below for anti-deflection screw location. (rear floor mount bracket only)

SIGBM20PF-N & CASBM20PF-N

Please note the stainless 2 qt. canisters are originally placed to the right of the waste bins. If the consumer prefers the canisters on the left, the top can easily be reconfigured by removing the 4 screws that fasten the top, rotate appropriately and then refasten with the 4 screws.

Signature Series and **Cascade Series**
with Blum Movento slides: Anti-deflection
screw location on slide.



Edge Series with Blum Tandem slides:
Anti-deflection screw location on
floor-mount bracket.

