

Century Components®

Cookie Tray Pull-out Installation Instructions

SIGCAN55PF-KBI and SIGCAN70PF-KBI instructions

Find Enclosed the following:

1 – Wood Pull-out with soft close slides & floor mounting brackets attached.

2 - Wood Stabilizer Slats

1) Place complete Pull-out into cabinet & find final location in relation to Partial Overlay, Full Overlay, or inset door application. Measure distance from front edge of cabinet to front of first floor mount bracket. Write this measurement down.

2) Remove complete Pull-out from cabinet & separate the slides from the Pull-out by releasing the front fixing clips.

3) Using measurement found in step 1, place slides with attached floor mount brackets onto cabinet floor & screw to floor of cabinet.

4) Extend slides out & insert through notches in back of wood Pull-out. Extend them all the way to the front until they click into the front fixing clips.

Wood Stabilizer Installation - Not Applicable with CTP130PF & CTP145PF

1) Install piece with groove up against the cabinet above with groove facing downward. (screws not included)

2) Install piece with roller bearing & predrilled hole/adjustable groove on back side of Pull-out locating it so that the bearing fits into groove of the top piece without the top of the roller bearing screw rubbing against top of groove (1-1/4" washerhead screws included).