

Century Components.

Base Filler Installation*

*Manufacturer Recommendation-Install filler to base cabinet before cabinet is installed to wall.

- 1) Align top of filler frame with top of adjacent base cabinet.
- 2) Fasten filler to adjacent base cabinet.
 - a) Slide filler to open position.
 - b) Place 1 screw at bottom of filler frame & into cabinet wall.
 - c) Place 1 screw at top of filler frame & into cabinet wall.
 - d) Place 4 remaining screws-2 at top & 2 at bottom of filler frame.
- 3) Install desired post or onlay to front of filler.
- 4) Install adjustable shelves at desired heights.